


# Talis

mit Stufen zum Einlegen (selbstbestücken)

## Einlege-Stufe Board tread

Montageanleitung  
Installation instruction



<b>68015</b>		<b>Starter-Set Start kit</b>			
<p>1 2</p> <p>x 1 K1-41931</p> <p>x 1 K1-41930</p>		<p>7 8</p> <p>x 1 K1-41911</p> <p>x 1 K1-41910</p>		<p>5</p> <p>x 2 K2-41900</p>	
<p>6</p> <p>x 2 K1-41940</p>		<p>40</p> <p>x 14 K3-02045 M10x25</p>		<p>41</p> <p>x 2 K3-04110 Ø10</p>	
<p>42</p> <p>x 8 K3-04198 Ø10</p>		<p>43</p> <p>x 14 K3-03051 M10</p>		<p>44</p> <p>x 12 K3-08001 Ø12 x 60</p>	
<p>45</p> <p>x 12 K3-06070 Ø10 x 60</p>		<p>59</p> <p>x 12 K3-06269 Ø6 x 35</p>		<p>63</p> <p>x 4 K3-05022 M8 x 20</p>	
<p>64</p> <p>x 12 K3-04010 Ø10,5</p>					


<b>68016</b>		<b>Ergänzungs-Set 1 step kit</b>			
<p>3 4</p> <p>x 1 K1-41921</p> <p>x 1 K1-41920</p>		<p>40</p> <p>x 4 K3-02045 M10 x 25</p>		<p>42</p> <p>x 4 K3-04198 Ø10</p>	
		<p>43</p> <p>x 4 K3-03051 M10</p>		<p>59</p> <p>x 6 K3-06269 Ø6 x 35</p>	






<b>68020</b>		<b>Stufen-Winkel Step support 1 step</b>	
<p>(9) (10)</p> <p>x1 K1-41060      x1 K1-41061</p>	<p>If more than 6 steps: Add (9) + (10)</p> <p>Wenn mehr als 6 Stufen: (9) + (10) hinzufügen</p> <p>Max. 6 Satz   sets</p>	<p>(40)</p> <p>x 2 K3-02045 M10 x 25</p>	<p>(43)</p> <p>x 2 K3-03051 M10</p>
			<p>(59)</p> <p>x 1 K3-06269 Ø6 x 35</p>


<b>68030</b>		<b>Steiggeländer für 6 Stufen Standard banister for 6 steps</b>	
<p>(14)</p> <p>x 6 K2-41050</p>	<p>(15)</p> <p>x 1 K1-01221</p>	<p>(16)</p> <p>x 6 K1-02130</p>	<p>(17)</p> <p>x 2 K2-04040</p>
<p>(18)</p> <p>1010mm      Ø 22mm</p> <p>x 6 K1-41055</p>			
<p>(19)</p> <p>Ø 40mm      2000mm</p> <p>x 1 K1-01100</p>			
<p>(46)</p> <p>x 6 K3-01004 M4x25</p>	<p>(47)</p> <p>x 6 K3-03004 M4</p>	<p>(48)</p> <p>x 12 K3-05006 M6x8</p>	<p>(53)</p> <p>x 4 K3-05050 M5x12</p>



**68040**

**Steiggeländer PROVA Starter-Set für 4 Stufen**  
**PROVA banister start for 4 steps**



<b>68041</b>		<b>Steiggeländer PROVA Ergänzungs-Set für 4 Stufen</b> <i>PROVA banister extension for 4 steps</i>	
<p>15</p>  <p>× 1 K1-01221</p>	<p>20</p>  <p>× 1 K2-41090</p>	<p>21</p>  <p>× 1 K1-41090</p>	<p>22</p>  <p>× 2 K1-01160</p>
			
<p>26</p>  <p>× 1 K1-01107</p>	<p>Ø 40mm</p> <p>1240mm</p> 		
<p>27</p>  <p>× 5 K1-18060</p>	<p>Ø 10mm</p> <p>1240mm</p> 		
<p>29</p>  <p>× 1 K2-14930</p>	<p>51</p>  <p>× 2 K3-02010 M10×70</p>	<p>53</p>  <p>× 5 K3-05050 M5 x 12</p>	<p>54</p>  <p>× 5 K3-08023 Ø8</p>


<b>68080 / 68081</b>		<b>Einlege-Stufe</b> <i>Board tread</i>		<b>80 cm / 100 cm</b>	
<p>11</p> 	<p>56</p>  <p>× 4 K3-03046 M6</p>	<p>58</p>  <p>× 4 K3-02220 M6×20</p>	<p>65</p>  <p>× 4 K3-04016 Ø6</p>		

68098	<i>Unterstützung Support</i>			OPTION	
 <p data-bbox="79 145 127 190">24</p> <p data-bbox="79 1444 199 1500">× 1 K1-41950</p>	 <p data-bbox="327 145 375 190">26</p> <p data-bbox="319 302 438 358">× 1 K1-41955</p>	 <p data-bbox="566 145 614 190">27</p> <p data-bbox="558 302 678 358">× 1 K1-41956</p>	 <p data-bbox="805 145 853 190">41</p> <p data-bbox="798 280 917 358">× 1 K3-04110 Ø10</p>	 <p data-bbox="1045 145 1093 190">43</p> <p data-bbox="1037 280 1157 358">× 1 K3-03051 M10</p>	 <p data-bbox="1284 145 1332 190">52</p> <p data-bbox="1276 280 1396 358">× 1 K3-02375 M10 x 75</p>
	 <p data-bbox="327 369 375 414">53</p> <p data-bbox="319 504 438 582">× 2 K3-05007 M5 x 5</p>	 <p data-bbox="566 369 614 414">54</p> <p data-bbox="558 504 678 582">× 1 K3-08002 Ø8 x 40</p>	 <p data-bbox="805 369 853 414">55</p> <p data-bbox="798 504 917 582">× 1 K3-06032 Ø6 x 60</p>		

A

11 ... 33

1 ... 7




A

11 ... 33

B

41 ... 61




B


41 ... 61

A

11 ... 33




+





B

41 ... 61






+













H	S				
	180	190	200	210	220
	mm	mm	mm	mm	mm
2	540	570	600	630	660
3	720	760	800	840	880
4	900	950	1000	1050	1100
5	1080	1140	1200	1260	1320
6	1260	1330	1400	1470	1540
7	1440	1520	1600	1680	1760
8	1620	1710	1800	1890	1980
9	1800	1900	2000	2100	2200
10	1980	2090	2200	2310	2420
11	2160	2280	2400	2520	2640
12	2340	2470	2600	2730	2860



H	S				
	180	190	200	210	220
	mm	mm	mm	mm	mm
2	360	380	400	420	440
3	540	570	600	630	660
4	720	760	800	840	880
5	900	950	1000	1050	1100
6	1080	1140	1200	1260	1320
7	1260	1330	1400	1470	1540
8	1440	1520	1600	1680	1760
9	1620	1710	1800	1890	1980
10	1800	1900	2000	2100	2200
11	1980	2090	2200	2310	2420
12	2160	2280	2400	2520	2640











13

A




14


A





15

A






















If more than  
6 steps:  
Add  
10 + 9





Wenn mehr als  
6 Stufen:  
10 + 9  
hinzufügen























43

B




44


B



45


B








47




B













  
 If more than  
 6 steps:  
 Add  
 (10) + (9)  
 Wenn mehr als  
 6 Stufen:  
 (10) + (9)  
 hinzufügen














We recommend  
using a support  
column from 8  
treads

Ab 8 Stufen  
empfehlen wir eine  
Abstützung der  
Treppe



Concrete  
Beton  
40 x 40 x 80 cm